

Sales/Customer Service
 Phone: 800.248.6564
 Fax: 620.473.3766



GNRK	GMRK	GNCR	PICKUP TRUCK YEAR, MAKE AND MODEL
CHEVY/GMC			CHEVY/GMC
1000	1000R	800R	1988-1998 Chevrolet & GMC 1/2, 3/4, & 1 Ton Long Bed Trucks 1999-2000 Chevrolet & GMC 3/4 & 1 Ton Heavy Duty Long Bed Trucks (Full C-Channel Frame)
1050	1050R	950R	1988-1998 Chevrolet & GMC 1/2, 3/4, & 1 Ton Short Bed Trucks 1999-2000 Chevrolet & GMC 3/4 & 1 Ton Short Bed Trucks (Full C-Channel Frame)
1059	1059R	959N	1999-2007 Chevrolet & GMC 1/2 & 3/4 Ton Light Duty All Beds (Tube Frame changing to C-Channel before axle)
1062	1062R	962R	2001-2007 Chevrolet & GMC 1 Ton Truck (With 2 bed cross members over the axle)
1057	1057R	959N	2007-2011 Chevrolet & GMC 1/2 Ton SHORT BED ONLY New Boxed Frame
1007	1007R	959N	2007-2011 Chevrolet & GMC 1/2 Ton LONG BED ONLY New Boxed Frame
1067	1067R	959N	2001-2010 Chevrolet & GMC 3/4 Ton Heavy Duty Short & Long Bed Trucks 2007-2010 Chevrolet & GMC 1 Ton (New Body) (With 1 bed crossmember over the axle)
1011	1011R	959N	2011 Chevrolet & GMC 3/4 & 1 Ton HD Long & Short Bed Trucks
1400	1400R	N/A	1973-1987 Chevrolet & GMC 1/2, 3/4, & 1 Ton (Requires Drilling)
FORD			FORD
1100	1100R	800R	1980-1998 Ford 3/4 & 1 Ton WITHOUT Overload Springs
1110	1110R	800R	1980-1998 Ford 3/4 & 1 Ton WITH Overload Springs (Requires Drilling 2 Holes)
1150	1150R	800R	1980-1996 Ford 1/2 Ton Trucks
1197	1197R	800R	1997-2003 Ford 1/2 & Light Duty 3/4 Ton Trucks, & 2004 Heritage Edition
1104	1104R	959N	2004-2011 Ford 1/2 Ton Trucks
1108	1108R	800RF	1999-2010 Ford 3/4 & 1 Ton Super Duty Long and Short Bed Trucks 2008-2010 F450 w/ factory installed bed
1111	1111R	800RF	2011 Ford 3/4 & 1 Ton Super Duty Long and Short Bed Trucks 2011 F450 w/ factory installed bed
DODGE			DODGE
1394	1394R	900R	1994-2001 Dodge 1/2 Ton Trucks All Beds 1994-2002 Dodge 3/4 Ton & 1 Ton Trucks All Beds
1316	1316R	900R	2002-2008 Dodge 1/2 Ton Long and Short Bed (Except Mega-Cab)
1307	1307R	907R	2006-2011 Dodge 1/2, 3/4 & 1 Ton Mega-Cab Trucks 2010-2011 Dodge 3/4 & 1 Ton Long Bed Gas Engine Trucks
1309	1309R	909R	2009-2011 Dodge 1/2 Ton Trucks All Beds (Only 4685 and RVK3000 with special post work with this hitch)
1310	1310R	900R	2003-2011 Dodge 3/4 & 1 Ton Long and Short Bed Trucks Except Mega-Cab and 2010-2011 3/4 and 1 Ton Long Bed Gas Engine
1300	1300R	N/A	1973-1993 Dodge 1/2, 3/4, & 1 Ton (Requires Drilling)
TOYOTA			TOYOTA
1251	1251R	1250R	2000-2006 Toyota Tundra All Beds
1257	1257R	1256R	2007-2011 Toyota Tundra All Beds (4585 is the sole accessory that works with this hitch)
NISSAN			NISSAN
1208	1208R	1218R	2004-2011 Nissan Titan All Beds
FLATBED			FLATBED
1500	1500R		Flatbed Kit 6" x 8" - 1/2" Plate - 1/8" Socket Top Stick Out